

Instruction manual for Becma Gas Forge

We would like to thank you for your visit to the Becma Gas Forge. For general questions, we are always at your disposal.

1. Installation

Please remove the gas and install the torch on the top of the case with the screws supplied. Please install the supplied hose in the nozzle direction into the burner. With the help of the nut, you can position the gas tap differently as desired. The GCE pressure regulator (3/8 ") with regulator and hose breakage protection must be screwed to the hose. We would like to draw your attention to the fact that the GCE pressure regulator and the gas bottle are LINK.

2. Ignite / Before operation

Please take the supplied lighter for lighting. Before lighting, we would like to point out that you first bring the pressure reducer down to the lowest level (0.5 bar). Please make sure the gas pipe is closed. Now you can open the bottle and slowly open the gas tap. Hold the lighter under the burner or shower head in the oven with your other hand. Thus you will eliminate unnecessary gas consumption and provide your safety.

3. Operation

After you have lit, you can now increase the pressure regulator up to 4.0 bar as required. 3 bar recommended. Please do not forget that the gas before use 5-10 min. Takes time until the requested temperature is reached.

!! If you use the gas in the open area, you need more time and gas consumption for the requested heat. In such cases, please close the rear and front side with the included folding doors !!

!! The stove can still smell a bit of paint in the first time. It is painted with an art feltshack, which only becomes firm when several times. In addition, it can perspire a bit, since the residual moisture from the brick stone peels off only after the heat.

The flame fires easily light blue when it is about 2-4cm long. It is bad only when the flame is very long, so that it goes to the ground, since the burner gets too little air.

!!! Please do not lose the eye contacts during the operation of the gas oven and do not remove yourself from the stove as an arm range. !!!

4. After operation

When you have finished your work, turn the gas bottle first, so the residual gas from the hose is burned. Then you can turn the gas pipe on the hose. Do not forget to reduce the pressure of the pressure reducer down to 0.5 bar.

We wish you much pleasure and success in working with the Becma Gas Forge.

OEZWERK
Machinery Trade & Forging Equipment
Weicheringer Str. 190
85051 Ingolstadt

Tel: +49 (0) 8450 92 56 47

Fax: +49 (0) 8450 92 56 67

Info@oezwerk.de

www.OEZWERK.de